



DISCHARGE LAMP CONTROL GEAR (240V, 50Hz SUPPLY)

Lamp Wattage	Type	Ballast Catalogue number	Weight kg	Capacitor Catalogue number	Value μ F	Ignitor/Starter Catalogue number	Weight kg	Circuit diagram no.
50	MBF	G53327-4	1.09	GC2435	6	-	-	A
80	MBF	G53333-4	1.25	GC2383	8	-	-	A
125(x)	MBF	G53306-4	2.3	GC2383	8	-	-	A
125(x)	MBF	G53271-4	1.87	GC2383	8	-	-	A
250	MBF	G53399-4	2.35	GC2370	13	-	-	A
400	MBF	G53397-4	3.5	GC2331	20	-	-	A
50	SON	G53389	1.87	GC2383	8	G53353-4	0.085	B
70	SON	G53320-T	1.87	GC2383	8	G53353-4	0.085	B
150	SON	G53400-4	2.3	GC2385	18	G53406	0.085	B
250	SON	G53398-4	3.5	GC2386	30	G53406	0.085	B
400	SON	G53371-4	4.6	2 x GC2331	20(each)	G53406	0.085	B
18	SOX	G53376-4	1.1	GC2420	5.5	-	-	F
35	SOX	G53331-4	1.09	GC2435	6	G53311	0.07	C
35	SOX	G53182-4	3.4	GC2384	15	-	-	D
35	SOX	G53131-4	4.2	GC2384	15	-	-	D
55	SOX	G53331-4	1.09	GC2435	6	G53421	0.07	C
55	SOX	G53182-4	3.4	GC2384	15	-	-	D
55	SOX	G53131-4	4.2	GC2384	15	-	-	D
90	SOX	G53365-4	4.0	GC2346	25	-	-	D
135	SOX	G53369-4	5.7	GC2281	13	-	-	D
140	SLI/H	G53365-4	4.0	GC2331	20	-	-	D
200	SLI/H	G53261-T	6.55	GC2382	35	-	-	E

FOR EASE OF INSTALLATION CONTROL GEAR CAN BE SUPPLIED ON PRE-WIRED GEAR TRAYS.

Discharge lamp circuit diagrams

